

# 13

## Bravilor Bonamat



[www.micromic.com](http://www.micromic.com)

\*Le informazioni contenute nel presente documento sono soggette a modifica e pertanto non sono vincolanti  
\*The information contained in this document is subject to change and is therefore not binding.

# Bravilor Bonamat



## BRV7170602102

7.170.602.102 - 7170602102  
Bravilor Bonamat  
ITA Caraffa in vetro  
ENG Glass Carafe



## BRV7150102301

7.150.102.301 - 7150102301  
Bravilor Bonamat  
ITA Filtri carta Ø110/360 250pz  
ENG Paper Filters Ø110/360 mm 250 pcs



## BRV7150103301

7.150.103.301 - 7150103301  
Bravilor Bonamat  
ITA Filtri carta Ø152/437mm 250pz  
ENG Paper Filters Ø152/437mm 250 pcs



## BRV7150104301

7.150.104.301 - 7150104301  
Bravilor Bonamat  
ITA Filtri carta Ø203/535 mm 250pz  
ENG Paper Filters Ø203/535 mm 250 pcs



## BRV7150101101

7.150.101.101 - 7150101101  
Bravilor Bonamat  
ITA Filtri carta Ø85/245mm 1000 pz  
ENG Paper Filters Ø85/245 mm 1000 pcs



## BRV7152101101

7.152.101.101 - 7152101101  
Bravilor Bonamat  
ITA Rotoli carta filtro 89 mm 4x2000  
ENG Filter Paper Rolls 89 mm 4x2000



## BRV7094100101

7.094.100.101 - 7094100101  
Bravilor Bonamat  
ITA Misurino 40 g  
ENG 40 g Measuring Scoop



## BRV6015001366

6.015.001.366 - 6015001366  
Bravilor Bonamat  
ITA Leva rubinetto  
ENG Tap Lever



## BRV6015001365

6.015.001.365 - 6015001365  
Bravilor Bonamat  
ITA Leva rubinetto  
ENG Tap Lever

# Bravilor Bonamat



## BRV6015001227

6.015.001.227 - 6015001227  
Bravilor Bonamat  
ITA Leva rubinetto  
ENG Tap Lever



## BRV6015001006

6.015.001.006 - 6015001006  
Bravilor Bonamat  
ITA Guarnizione per rubinetto  
ENG Tap Gasket



## BRV6015001213

6.015.001.213 - 6015001213  
Bravilor Bonamat  
ITA Guarnizione per rubinetto  
ENG Tap Gasket



## BRV6243232001

6.243.232.001 - 6243232001  
Bravilor Bonamat  
ITA Vetro livello Ø12x281mm  
ENG Level Glass Ø12x281mm



## BRV6242193001

6.242.193.001 - 6242193001  
Bravilor Bonamat  
ITA Vetro livello Ø12x9x257 mm  
ENG Level Glass Ø12x9x257 mm



## BRV6240134001

6.240.134.001 - 6240134001  
Bravilor Bonamat  
ITA Coperchio tubo vetro livello  
ENG Glass level tube cap



## BRV6101062001

6.101.062.001 - 6101062001  
Bravilor Bonamat  
ITA Diffusore portadoccia  
ENG Showerhead diffuser



## BRV7091600101

7.091.600.101 - 7091600101  
Bravilor Bonamat  
ITA Molla ferma filtro  
ENG Filter retaining spring



## BRV6000229122

6.000.229.122 - 6000229122  
Bravilor Bonamat  
ITA Coclea avanzamento prodotto  
ENG Product deed auger

# Bravilor Bonamat



## BRV6229803001

6.229.803.001 - 6229803001

Bravilor Bonamat

ITA Elica miscelatore

ENG Mixer Blade



## BRV6011001112

6.011.001.112 - 6011001112

Bravilor Bonamat

ITA Guarnizione O-ring 0120-30 Silicone rosso

ENG O-ring gasket 0120-30 Red Silicone



## BRV6030071020

6.030.071.020 - 6030071020

Bravilor Bonamat

ITA Guarnizione perno motore mixer

ENG Motor Shaft Gasket for Mixer

# Bravilor Bonamat



## BRV6101061000

6.101.061.000 - 6101061000

Bravilor Bonamat

ITA Caldaia 2175W 240V

ENG Boiler 2175W 240V



## BRV6242206000

6.242.206.000 - 6242206000

Bravilor Bonamat

ITA Resistenza 100/240V

ENG Heating element 100/240V



## BRV6301002000

6.301.002.000 - 6301002000

Bravilor Bonamat

ITA Resistenza 2160W 240V

ENG Heating element 2160W 240V



## BRV6229806001

6.229.806.001 - 6229806001

Bravilor Bonamat

ITA Guarnizione sagomata silicone

ENG Shaped silicone gasket



## BRV6019033014

6.019.033.014 - 6019033014

Bravilor Bonamat

ITA Tubo silicone Ø15.5x9.5 mm

ENG Silicone Tube Ø15.5x9.5 mm



## BRV6016001035

6.016.001.035 - 6016001035

Bravilor Bonamat

ITA Valvola magnetica 2,5l/min Ø10mm

ENG Magnetic valve 2.5l/min Ø10mm



## BRV6003012024

6.003.012.024 - 6003012024

Bravilor Bonamat

ITA Cavo alimentazione 16A 250V 1300 mm

ENG Power Cable 16A 250V 1300 mm



## BRV6016008052

6.016.008.052 - 6016008052

Bravilor Bonamat

ITA Termostato a contatto 130°C 16A 250V

ENG Contact Thermostat 130°C 16A 250V



## BRV6016008057

6.016.008.057 - 6016008057

Bravilor Bonamat

ITA Termostato a contatto 16A 250V

ENG Contact Thermostat 16A 250V



## BRV6004001051

6.004.001.051 - 6004001051

Bravilor Bonamat

ITA Interruttore bipolare 10A 250V

ENG Bipolar Switch 10A 250V



## BRV6004002064

6.004.002.064 - 6004002064

Bravilor Bonamat

ITA Relay di potenza 220V 16A

ENG Power Relay 220V 16A



## BRV6101072000

6.101.072.000 - 6101072000

Bravilor Bonamat

ITA Piastra elettrica 110/240V

ENG Electric plate 110/240V



## BRV7190101212

7.190.101.212 - 7190101212

Bravilor Bonamat

ITA Decalcificante Renegite 1 cartone 4x15 bustine

ENG Renegite Descaler 1 carton 4x15 sachets 2